





100% of Actual Size
Screen Print

POSITION A




100% of Actual Size
Screen Print

POSITION B



100% of Actual Size
Pad Print

POSITION D



POSITION E




100% of Actual Size
Direct Digital

POSITION D




POSITION E



Please note when pen is printed in position D,
print is not visible when in the notebook holder.




100% of Actual Size
Pad Print





100% of Actual Size
Pad Print





100% of Actual Size
Screen Print (one colour)

